


HUSKY 40 STROKE CONFIGURATION



Distance from Horse's Head to Saddle Bearing	Distance from Saddle Bearing to Tail Bearing	Crank Housing Travel	Stroke	Total Stroke
49.00	49.75	14	13.79	27.58
49.00	57.25	14	11.98	23.97
56.50	42.25	14	18.72	37.44
56.50	49.75	14	15.90	31.80
49.00	49.75	18	17.73	35.46
49.00	57.25	18	15.41	30.81
56.50	42.25	18	24.07	48.14
56.50	49.75	18	20.44	40.88